

## Putting a call on hold

1. Press Hold soft key, caller is put on hold.
  2. To retrieve the call press Resume soft key.
- Note: with more than one active call, select desired call by sliding screen and use the corresponding soft key to hold or resume.

## Multiparty conference

1. Once in line with 1st caller, press Conference soft key, 1st caller is put on hold.
2. Then call the 2nd number.
3. After, 2nd call is established, press Conference soft key to set up the conference.

## Call transfer

Attended transfer:

1. Press Transfer soft key during the active conversation, the call is put on hold.
2. Dial the second telephone number.
3. When the call is answered, then press Transfer soft key to complete the operation.



Blind transfer:

1. Press Transfer soft key during the active conversation, the call will be held.
2. Then enter the 2nd telephone number and press Transfer soft key.

## Call forward

1. Press Phone Settings icon > Line > Select the line> Forward Settings.
2. Enter the destination number and the type of forward.

## Call Mute


1. Press  to Mute the microphone during the call.
2. Press  again to un-mute the conversation.

## Call list


1. Press Call Log icon .
2. Scroll the list using navigation key or slide the screen

## Phonebook

Access phonebook:


1. Press Contact icon.
2. Select All Contacts or other group.
3. To dial an entry, press Dial icon .

Add new entry:


1. Press Contact icon, Press All Contacts or other group > Press Add icon.
2. Enter name and number and press OK icon .

## Programmable keys

DSS keys :

1. You can use the phone web interface to configure the keys of the screen.
2. You can press any keys which is blank or long-press the key that configured, select a type and value, press .


Other keys :

1. You can configure shortcuts for the navigation keys and softkeys on web UI.
2. You can press Phone setting icon > Key, select the SoftkeyScreen you need, then select among the configurable items, and select your desired type and value, press .



## Redial

1. Press  redial a call number.

## Do not disturb

1. Press DND icon  when standby or click Phone Settings icon > DND.
2. Select the Mode.

## Voice message

1. To access your voice mailbox, press Voice message key  or Voice message icon  number of message be indicated if provided by your server or PBX.
2. Select the line and press phone icon to call.

## Bluetooth


1. Press Bluetooth icon in the status bar to open Bluetooth.
2. Press Settings icon > Bluetooth to enter the Bluetooth Interface.

After opening, it displays the scanned Bluetooth list,select any device, and click on the device pairing.

## WiFi


1. Press WiFi icon in the status bar to open WiFi.
2. Press Settings icon > WiFi to enter the WiFi configuration Interface.
3. After opening, it displays the available WiFi list.
4. Select the WiFi you want to connect
5. Enter the appropriate password to connect to the WiFi. The default is DHCP mode.

# XonTel




## XT-50G IP Phone Quick Installation Guide


## Packaging list



## Screen icon




## Keys features




## Installation the device


- Attach the stand and adjust the angle of the touch screen



- Adjust shutter switch




- Wall mounting (Wall stand need buy separately)



### Connecting to the Device

Please connect power adapter, network, PC, headset, and handset to the corresponding ports as described in below picture.

- ① USB port: connect USB device (USB flash drive, USB Headset)
- ② Power port: connect the power adapter.
- ③ Network port: connecting local area network or Internet.
- ④ PC port: the network port connect to the computer.
- ⑤ Headset port: connect headset.
- ⑥ Handset port: connect IP Phone handset.



## Configuration

### Configuration via Phone

1. Press Phone Settings icon
2. Select Ethernet Settings: To configure the Network Settings (DHCP/Static/PPPoE)
3. Select Line: To configure enable the account, Input the SIP server address, port, user name, password etc.

### Configuration via Web

1. Get the IP address from the phone: Press Phone Settings icon > Common Information.
2. Login: Input the IP address in the web browser. The PC and phone should be in the same IP address segment (The default username and password are both 'admin'.)
3. Configure: Select network/Account, etc. And fill the relevant content.

## Language setting

1. Press Phone settings icon > Language & Input > Language.
2. Select the desired language.

## Making a call

1. Pre-dialing: enter the phone number and pick up the handset.
2. Direct dialing: lift the handset and enter the phone number.
3. Handsfree: enter phone number and press or vice versa.
4. Headset: enter phone number and press or vice versa.
5. Dial icon: Click dial icon and then enter the phone number.
6. Designated line: press line key, enter phone number and press dial key.

## Accepting a call

1. With the handset: pick up the handset.
2. With a headset: press .
3. With the handsfree: press .